

# **PRO MINI SOCCER**

#### **GETTING STARTED**



Thank you for choosing the SKLZ Pro Mini Soccer. We are dedicated to providing you with the best tools and instruction possible to help you prepare for your sport. If there is anything else we can do to help, don't hesitate to send us an email at help@4implus.com or give us a call toll-free 1-800-446-7587.

#### **BEFORE YOU BEGIN:**

- Read all instructions carefully before using. Failure to do so may result in injury or damage to the product.
- Always check for wear and tear before use. If any is found, do not use the product.
- If you are missing any Pro Mini Soccer components, please contact Implus customer service toll-free at 1-800-446-7587.
- Adult assembly required.

#### **AWARNING:**

- **CHOKING HAZARD:** Contains small parts. Not for children under 3 years of age. Athletes under 18 years of age should use only under adult supervision.
- Regularly check for wear and tear. Stop using the Pro Mini Soccer if any part of it breaks. Failure to do so could result in injury.
- When in use, make sure the Pro Mini Soccer is set up in a clear area to avoid injury.
- Any alteration of this product or its components will result in a disclaimer of liability.


#### **ACAUTION:**

- Keep away from fire and heat sources.
- Do not leave the Pro Mini Soccer outdoors for extended periods of time.
- Avoid storing the Pro Mini Soccer in extremely hot or cold environments, as this could reduce the life span of the product.
- When in use, make sure the Pro Mini Soccer is set up in a clear area to avoid damage to property. When done, disassemble the Pro Mini Soccer and store after use. Do not leave Pro Mini Soccer outdoors.

#### 1-YEAR LIMITED WARRANTY

This warranty does not cover damages resulting from accidents, misuse, abuse or lost merchandise. Need proof of purchase for warranty coverage. Questions? Email help@4implus.com or call toll-free 1-800-446-7587.

## **IN THE BOX**



A NET

B TOP FRAME POLE

**G** BACK FRAME POLE







### **ASSEMBLY**



**STEP 1:**Take top frame pole **(B)** and slide through sleeve at top of net **(A)** where SKLZ logo is located.

Note: Logo should face out.



**STEP 2:** Place corner joints **(E)** on top frame pole on both the right and left sides.



STEP 3: Slide left side pole (D) into net sleeve, and connect to top corner joint (E). Repeat on right side.



**STEP 4:**Connect bottom corner joint **(E)** to bottom of left side pole **(D)**. Repeat on right side.

Note: Bottom corner joints should face back of net.



STEP 5: Slide another pole **(D)** into left bottom sleeve of net, and connect to corner joint. Repeat on right side.



**STEP 6:**Connect back corner joint **(F)** to bottom left pole.
Repeat on right side.

Note: Holes on corner joints should face up.



STEP 7: Slide back frame pole (C) into net sleeve, and connect to back corner joint on left pole. Repeat on right side.



**STEP 8:** Insert the fiberglass pole **(G)** into back corner joint **(F)** hole. Repeat on right side.



STEP 9: Locate black tabs on the net. Loop over fiberglass poles on the right and left sides.